







These guidelines are based upon fire testing of the generator enclosure and the manufacturer's requirement for air flow for proper operation. Local codes may be different and more restrictive than what is described here.

Clearance from the ends and front of the generator should be 36 inches. This would include shrubs, trees and any kind of vegetation. Clearance at the top should be a minimum of 48 inches from any structure, overhang or projections from the wall. The generator should not be placed under a deck or other structure that is closed in and would limit or contain air flow.

